

Deer Hunter

Safety Instructions

1. Be sure that there is plenty of clearance between the player and spectators.
2. Keep spectators clear from the sides and back of canvas to prevent them from being struck by a deflected or errant throw.
3. If using game outdoors, it is strongly suggested that you use the stakes provided on either side of the bottom supports. Use sandbags on pavement. And in a breeze, use sandbags with the stakes.
4. NEVER USE THE GAME IN STRONG WINDS OR LIGHTENING!
5. Use caution when setting up or taking down the game. The sections of tubing can come apart and fall down causing injury.
6. Use only the accessories included with the game.

Deer Hunter

Packing List

<u>Description</u>	<u>Quantity</u>
Canvas	1
ìFour-Wayî Fittings	2
ìElbowî Fittings	2
Lengths of Tubing 44.5î (<i>Swedged</i>)	4
Lengths of Tubing 41.5î (<i>Unswedged</i>)	4
Lengths of Tubing 36î (<i>with rubber tips</i>)	4
Crossbow	1
Velcro Darts	15
Stakes	4
Carrying Case	1



Deer Hunter

Assembly Instructions

1. Select a level area to operate game with plenty of room to allow for a line to form.
2. Assemble framework, per sketch. Note that the eight longer pieces of tubing are used to form the sides (2 per side) while the four shorter crimped pieces are to be used to create the base. (Be sure to tighten down the fittings using the small bolts on them.)
3. Attach canvas to the framework using the Velcro straps.
4. If using game outdoors, it is strongly suggested that you use the stakes provided on either side of the bottom supports. Use sandbags on pavement. And in a breeze, use sandbags with the stakes.
5. Never fold up canvas wet. Always allow to dry thoroughly first. Your canvas may have powder on it to prevent sticking during shipment. Simply use a dry cloth to dust it off.

Canvas Care

1. If game becomes wet, dry thoroughly before storing.
2. Fold the canvas INWARD to help protect and keep it clean.
3. Canvas can be cleaned with rubbing alcohol when necessary. If your game involves velcro, clean the hook and loop fabric with dry brush to knock out the dirt. If velcro fabric is badly soiled, use upholstery cleaner.

Frame Set-Up

