

Teen Striker

Safety Rules

1. Keep the *Teen Striker* away from power lines.
2. Do not operate the *Teen Striker* during a storm.
3. Periodically, check the bolts to make sure they are tightly fastened.
4. Use only on level, firm ground. Stake the unit down if necessary.
5. Block off a “striking zone” with plenty of room for the participant to safely swing the mallet with no danger of hitting a spectator or passer-by.
Note: occasionally the mallet will bounce off the side of the rubber pad, so make sure the spectators are kept clear of this area.
6. Only one person at a time allowed in the “strike zone”.
7. Do not leave the unit unattended.
8. Do not allow anyone to climb on the *Teen Striker*.

Teen Striker

Packing List

<u>Description</u>	<u>Quantity</u>
Bell	1
Mallet	1
Steel Slide/Puck	1
3.25” Spacer	1
1/2” x 1.5” Hex Head Bolt	4
1/2” x 5” Hex Head Bolt	1
1/2” Lock Nut	5
1/2” Washer	3



TWISTER DISPLAY

PO Box 2704

East Liverpool, OH 43920

Phone: 330-386-1270 Fax: 330-386-0418

Order Desk: 800-637-3656

Email: sales@twisterdisplay.com

Teen Striker

Initial Assembly

1. Remove all packing, and remove unit from pallet. Lay frame on back so that the wheels are on the ground. Place something solid (such as concrete blocks) under both the front and back edges of the frame in order to support it and keep it parallel to the ground.
2. Block the wheels so that the unit will not roll or move during assembly.
3. Slide the tower into the frame until it is against the base of the frame and the bolt holes line up. Attach the tower to the frame using the 1 1/2" bolts at the bottom of the frame and the 3" bolts at the top of the frame.
4. Attach the bell using the 5" bolt. Put the bolt through the bell. Then slide a washer onto the bolt behind the bell. Then slide the spacer onto the bolt, followed by another washer. Then put the bolt through the hole at the top of the striker and put a washer onto the bolt along with a locking washer.

Teen Striker

Instructions

Set Up

1. Select a level area for set up.
2. Unhook trailer and lights from tow vehicle and roll to set up area.
3. Carefully raise the unit into its upright position.
Assistance will be required.
4. REVIEW SAFETY RULES!!

Operation

1. Check to see that the unit is on a firm and level surface.
2. Inspect the mallet to make sure that the head is securely attached to the handle.
3. *Block off a "striking zone" with plenty of room for the participant to safely swing the mallet with no danger of hitting a spectator or passer-by. Note: occasionally the mallet will bounce off the side of the rubber pad, so make sure the spectators are kept clear of this area.*
4. If the Easy Striker moves or "walks" during use, drive 4 stakes through the 4 holes on the sides of the unit.
5. The level of difficulty can be adjusted by raising or lowering the spacer under the back end of the high striker arm.

Take Down

1. Raise the support legs and secure with the locking nut and wrap the safety chain around the frame to be certain the the legs will not drop down while in tow.
2. Carefully lower the unit back onto its wheels. *Assistance will be required.*