



<u>DESCRIPTION</u>	<u>QUANTITY</u>
VINYL CANVASES	4
"THREE-WAY" FITTINGS	8
PIPE A (UNSWEDGED)	12
PIPE B (SWEDGED)	12
STAKES	4
PIPE CARRYING CASES	2
MESH ACCESSORIES BAGS	4
VARIOUS GAME ACCESSORIES	






- 1. Select a level area to operate game with plenty of room.
- 2. Assemble framework, per photos below. (Be sure to tighten down the fittings using the small bolts on them.)











# COLORIUS GRANUES GRANU

- 3. Attach canvas to the framework using the Velcro straps.
- **4.** If using game outdoors, it is strongly suggested that you use the stakes provided. (Use sandbags on pavement.) And in a breeze, use sandbags with the stakes.
- **5.** Never fold up canvas wet. Always allow to dry thoroughly first.





- 1. Use only under adult supervision.
- 2. Be sure that there is plenty of clearance between the player and spectators.
- 3. Keep spectators clear of the game to prevent them from being struck by a deflected or errant throw.
- **4.** If using game outdoors, it is strongly suggested that you use the stakes provided. (Use sandbags on pavement.) And in a breeze, use sandbags with the stakes.

# 5. <u>NEVER USE THE GAME IN STRONG WINDS OR LIGHTENING!!</u>

- **6.** Use caution when setting up or taking down the game. The sections of tubing can come apart and fall down causing injury.
- 7. Use only the accessories included with the game. Do not use hard balls or other hard objects.

Twister Display

49207 Calcutta Smith Ferry Road East Liverpool, OH 43920

1 800 637-3656 www.TwisterDisplay.com

# FROGGY FLY FLING

# **Packing List**

<u>DESCRIPTION</u>	QUANTITY
PAINTED VINYL CANVAS	1
"FOUR-WAY" FITTINGS	2
" <i>ELBOW</i> " FITTINGS	2
LENGTHS OF TUBING (SWEDGED)	4
LENGTHS OF TUBING (UNSWEDGED)	4
LENGTHS OF TUBING (CRIMPED)	4
STAKES	4
INSECTS	12
LAUNCHER	1
RUBBER MALLET	1
STORAGE/CARRYING CASE	1

### **Twister Display**




- Select a level area to operate game with plenty of room to allow for a line to form.
- 2. Assemble framework, per sketch. Note that the eight longer pieces of tubing are used to form the sides (2 per side) while the four shorter capped pieces are to be used to create the base. (Be sure to tighten down the fittings using the small bolts on them.)
- 3. Attach canvas to the framework using the Velcro straps.
- **4.** If using game outdoors, it is strongly suggested that you use the stakes provided on either side of the bottom supports. Use sandbags on pavement. And in a breeze, use sandbags with the stakes.
- 5. Never fold up canvas wet. Always allow to dry thoroughly first.

# Canvas Care

- 1. If game becomes wet, dry thoroughly before storing.
- 2. Fold the canvas *inward* to help protect and keep it clean.
- **3.** Canvas can be cleaned with rubbing alcohol when necessary. If your game involves Velcro, clean the hook and loop fabric with dry brush to knock out the dirt. If Velcro fabric is badly soiled, use upholstery cleaner.

#### **Twister Display**

# FROGGY FLY FLING



## **Twister Display**



- 1. Use only under adult supervision.
- Be sure that there is plenty of clearance between the player and spectators.
- 3. Keep spectators clear from the sides and back of canvas to prevent them from being struck by a deflected or errant hit.
- 4. If using game outdoors, it is strongly suggested that you use the stakes provided on either side of the bottom supports. Use sandbags on pavement. And in a breeze, use sandbags with the stakes.
- 5. NEVER USE THE GAME IN STRONG WINDS OR LIGHTENING!!
- 6. Use caution when setting up or taking down the game. The sections of tubing can come apart and fall down causing injury.
- 7. Use only the insects included with the game. Do not use hard balls or other hard objects.

#### **Twister Display**



DESCRIPTION	QUANTITY
PAINTED VINYL CANVAS	1
"FOUR-WAY" FITTINGS	2
<i>"ELBOW"</i> FITTINGS	2
LENGTHS OF TUBING (SWEDGED)	4
LENGTHS OF TUBING (UNSWEDGED)	4
LENGTHS OF TUBING (CRIMPED)	4
STAKES	4
SCOOPS	4
TURTLES	12
STORAGE/CARRYING CASE	1

### **Twister Display**




- Select a level area to operate game with plenty of room to allow for a line to form.
- 2. Assemble framework, per sketch. Note that the eight longer pieces of tubing are used to form the sides (2 per side) while the four shorter capped pieces are to be used to create the base. (Be sure to tighten down the fittings using the small bolts on them.)
- 3. Attach canvas to the framework using the Velcro straps.
- **4.** If using game outdoors, it is strongly suggested that you use the stakes provided on either side of the bottom supports. Use sandbags on pavement. And in a breeze, use sandbags with the stakes.
- 5. Never fold up canvas wet. Always allow to dry thoroughly first.

# Canvas Care

- 1. If game becomes wet, dry thoroughly before storing.
- 2. Fold the canvas *inward* to help protect and keep it clean.
- **3.** Canvas can be cleaned with rubbing alcohol when necessary. If your game involves Velcro, clean the hook and loop fabric with dry brush to knock out the dirt. If Velcro fabric is badly soiled, use upholstery cleaner.

#### **Twister Display**

# Bator Bulp



### **Twister Display**



- 1. Use only under adult supervision.
- 2. Be sure that there is plenty of clearance between the player and spectators.
- 3. Keep spectators clear from the sides and back of canvas to prevent them from being struck by a deflected or errant throw.
- 4. If using game outdoors, it is strongly suggested that you use the stakes provided on either side of the bottom supports. Use sandbags on pavement. And in a breeze, use sandbags with the stakes.
- 5. NEVER USE THE GAME IN STRONG WINDS OR LIGHTENING!!
- 6. Use caution when setting up or taking down the game. The sections of tubing can come apart and fall down causing injury.
- 7. Use only the turtles included with the game. Do not use hard balls or other hard objects.

#### **Twister Display**



<u>DESCRIPTION</u>	QUANTITY
VINYL CANVAS	1
"FOUR-WAY" FITTINGS	2
<i>"ELBOW</i> " FITTINGS	2
PIPE A — 41.5"	4
PIPE B — 34" (TAPERED)	4
PIPE C — 36" (FEET)	4\
HORN	1
HORN-HOLDER	1
STAKES	4
SMALL RINGS	3
LARGE RINGS	3
STORAGE/CARRYING CASE	1


### **Twister Display**



- 1. Select a level area to operate game with plenty of room to allow for a line to form.
- 2. Assemble framework, per sketch. Note that the eight longer pieces of tubing are used to form the sides (2 per side) while the four shorter capped pieces are to be used to create the base. (Be sure to tighten down the fittings using the small bolts on them.)
- 3. Attach canvas to the framework using the Velcro straps.
- 4. Place the horn-holder through the back and attach Velcro.




5. <u>IMPORTANT</u>: Be sure the protective PVC sleeve is covering the peg. *This is important* for the safety of the players.



- 6. If using game outdoors, it is strongly suggested that you use the stakes provided on either side of
- the bottom supports. Use sandbags on pavement. And in a breeze, use sandbags with the stakes.
- 7. Never fold up canvas wet. Always allow to dry thoroughly first.

### **Twister Display**

# Ring the Rhino



### **Twister Display**

49207 Calcutta Smith Ferry Road

East Liverpool, Ohio 43920
1 800 637-3656 — 1 (330) 386-1270

www.twisterdisplay.com



- 1. Use only under adult supervision.
- 2. **IMPORTANT**: Be sure the protective PVC sleeve is covering the peg.
- 3. Be sure that there is plenty of clearance between the player and spectators.
- 4. Keep spectators clear from the sides and back of canvas to prevent them from being struck by a deflected or errant throw.
- 5. If using game outdoors, it is strongly suggested that you use the stakes provided on either side of the bottom supports. Use sandbags on pavement. And in a breeze, use sandbags with the stakes.
- 6. NEVER USE THE GAME IN STRONG WINDS OR LIGHTENING!!
- 7. Use caution when setting up or taking down the game. The sections of tubing can come apart and fall down causing injury.
- 8. Use only the toss items included with the game. Do not use hard balls or other hard objects.

# Canvas Care

- **1.** If game becomes wet, dry thoroughly before storing.
- 2. Fold the canvas *inward* to help protect and keep it clean.
- **3.** Canvas can be cleaned with rubbing alcohol when necessary. If your game involves Velcro, clean the hook and loop fabric with dry brush to knock out the dirt. If Velcro fabric is badly soiled, use upholstery cleaner.

### **Twister Display**



DESCRIPTION	QUANTITY
PAINTED VINYL CANVAS	1
"FOUR-WAY" FITTINGS	2
" <i>ELBOW</i> " FITTINGS	2
LENGTHS OF TUBING (SWEDGED)	4
LENGTHS OF TUBING (UNSWEDGED)	4
LENGTHS OF TUBING (CRIMPED)	4
STAKES	4
PLUSH TURTLES	12
STORAGE/CARRYING CASE	1

### **Twister Display**

# TURTLE RESCUE

## **Assembly Instructions**


- 1. Select a level area to operate game with plenty of room to allow for a line to form.
- 2. Assemble framework, per sketch. Note that the eight longer pieces of tubing are used to form the sides (2 per side) while the four shorter capped pieces are to be used to create the base. (Be sure to tighten down the fittings using the small bolts on them.)
- 3. Attach canvas to the framework using the Velcro straps.
- **4.** If using game outdoors, it is strongly suggested that you use the stakes provided on either side of the bottom supports. Use sandbags on pavement. And in a breeze, use sandbags with the stakes.
- **5.** Never fold up canvas wet. Always allow to dry thoroughly first.

### Canvas Care

- 1. If game becomes wet, dry thoroughly before storing.
- 2. Fold the canvas *inward* to help protect and keep it clean.
- **3.** Canvas can be cleaned with a wet sponge when necessary. If your game involves Velcro, clean the hook and loop fabric with dry brush to knock out the dirt. If Velcro fabric is badly soiled, use upholstery cleaner.

#### **Twister Display**

# TURILE BESGUE



### **Twister Display**

# TUBILE BESGUE

## **Safety Instructions**

- 1. Use only under adult supervision.
- 2. Be sure that there is plenty of clearance between the player and spectators.
- 3. Keep spectators clear from the sides and back of canvas to prevent them from being struck by a deflected or errant throw.
- 4. If using game outdoors, it is strongly suggested that you use the stakes provided on either side of the bottom supports. Use sandbags on pavement. And in a breeze, use sandbags with the stakes.
- 5. <u>NEVER USE THE GAME IN STRONG WINDS OR LIGHTENING!!</u>
- 6. Use caution when setting up or taking down the game. The sections of tubing can come apart and fall down causing injury.
- 7. Use only the **plush turtles** included with the game. Do not use hard balls or other hard objects.

#### **Twister Display**