Easy Dunker | EconoDunker | Maintenance

For both Easy Dunkers & EconoDunkers...

- Periodically, check tank and frame for any sharp edges.
- Check seat hinges, bolts and seat spring to be sure that they are solid and secure. Replace if they show signs of wear.
- Replace any parts that show signs of wear.
- If you find it necessary to replace a window, be sure to only use an impact resistant polycarbonate. Anything else will burst on impact, resulting in a dangerous situation. <u>Do not use plexiglass.</u> Note: We have replacement window kits available.

For *Easy Dunkers* (with trailer) only....

- Check the wiring for the brake lights for any cuts or crimps.
- Always check brake lights and turns signals, before towing.
- Check the rope to hold wing frame against tank for wear.
- Check safety chain and BOTH tongue pins.
- Replace any parts that show signs of wear.