

JUNIOR STRIKER

Set-up/Safety

Instructions





1 800 637-3656 ~ www.twisterdisplay.com

JUNIOR STRIKER

Packing List

<u>Description</u>	<u>Quantity</u>
Base Unit	1
Tower	1
Bell	1
Mallet	1
Steel Slide "Puck"	1
3 1/4" Spacer	1
1/2" X 1 1/2" Hex Head Bolts	4
1/2" X 5" Hex Head Bolt	1
1/2" Lock Nuts	5
1/2" Washers	3
5/8" X 6" Hex Head Bolts	2
5/8" Lock Nuts	2
Tires	2



Visit our website at: www.twisterdisplay.com

TWISTER DISPLAY

P.O. Box 2704 East Liverpool, OH 43920

Ph: (330) 386-1270 Fx: (330) 386-0418

Order Desk: (800) 637-3656

Email: sales@twisterdisplay.com

JUNIOR STRIKER

Initial Assembly

Remove all packing, and remove unit from pallet and crate.


1. Attach the tires using the 5/8" bolts and locking nuts.




2. Lay frame on its back, and slide the tower into the frame until it is against the base of the frame and the bolt holes line up. Attach the tower to the frame using two 1 1/2" bolts on each side.



3. Slide puck onto the rail (the wide end downward).



4. Attach the bell using the 5" bolt. Put the bolt through the bell. Then, slide a washer onto the bolt behind the bell. Slide the spacer onto the bolt, followed by another washer. Then, put the bolt through the hole at the top of the striker and put a washer onto the bolt, locking it in place with a lock nut.



JUNIOR STRIKER


Operating Instructions

SET UP

1. Select a level area for set up.
2. Carefully raise the unit into its upright position. *Assistance may be required.*
4. **REVIEW SAFETY RULES.**

OPERATION

1. Check to see that the unit is on a firm and level surface.
2. Inspect the mallet to make sure that the head is securely attached to the handle.
3. Block off a “striking zone” with plenty of room for the participant to safely swing the mallet with no danger of hitting a spectator or passer-by. Note: Occasionally the mallet will bounce off the side of the rubber pad, so make sure the spectators are kept clear of this area.
4. If the Junior Striker moves or “walks” during use, drive 4 heavy-duty stakes (not included) through the 4 holes on the sides of the unit.
5. The level of difficulty can be adjusted by raising or lowering the spacer under the back end of the high striker arm.



TAKE DOWN

Carefully lower the unit back onto its wheels. *Assistance may be required.*

**Once assembled,
your Junior Striker
should look like
this...**



1 800 637-3656 ~ www.twisterdisplay.com




JUNIOR STRIKER ***Safety Rules***



Be sure to review ALL safety rules with Junior Striker operator prior to use.

1. Keep *JUNIOR STRIKER* away from power lines.
2. Do not operate *JUNIOR STRIKER* during a storm.
3. Periodically, check the bolts to make sure they are fastened tight.
4. Use only on level, firm ground. Stake the unit down if necessary.
5. Block off a “striking zone” with plenty of room for the participant to safely swing the mallet with no danger of hitting a spectator or passer-by. Note: Occasionally the mallet will bounce off the side of the rubber pad, so make sure the spectators are kept clear of this area.
6. Only one person at a time is allowed in the “strike zone”.
7. Do not leave the unit unattended.
8. Do not allow anyone to climb on the *JUNIOR STRIKER*.



Visit our website at: www.twisterdisplay.com

TWISTER DISPLAY

P.O. Box 2704 East Liverpool, OH 43920

Ph: (330) 386-1270 Fx: (330) 386-0418

Order Desk: (800) 637-3656

Email: sales@twisterdisplay.com