

THE SPORTS GAME CUBE

Safety Instructions

1. Use only under adult supervision.
2. Be sure that there is plenty of clearance between the player and spectators.
3. Keep spectators clear of the game to prevent them from being struck by a deflected or errant throw.
4. If using game outdoors, it is strongly suggested that you use the stakes provided. (Use sandbags on pavement.) And in a breeze, use sandbags with the stakes.
5. **NEVER USE THE GAME IN STRONG WINDS OR LIGHTENING!!**
6. Use caution when setting up or taking down the game. The sections of tubing can come apart and fall down causing injury.
7. Use only the accessories included with the game. Do not use hard balls or other hard objects.

Twister Display

49207 Calcutta Smith Ferry Road
East Liverpool, OH 43920

1 800 637-3656

www.TwisterDisplay.com