

# *Tic-Tac-Toss*

## Packing List

<u>DESCRIPTION</u>	<u>QUANTITY</u>
GRAPHIC CANVAS	1
"FOUR-WAY" FITTINGS	2
"ELBOW" FITTINGS	2
PIPE A (44.5")	4
PIPE B (17")	4
PIPE C (36")	4
RED BALLS	5
BLUE BALLS	5
STAKES	4
STORAGE/CARRYING CASE	1

## Twister Display

*49207 Calcutta Smith Ferry Road*

*East Liverpool, Ohio 43920*

1 800 637-3656 — 1 (330) 386-1270

[www.twisterdisplay.com](http://www.twisterdisplay.com)

# *Tic-Tac-Toss*

## **Assembly Instructions**

1. Select a level area to operate game with plenty of room to allow for a line to form.
2. Assemble framework, per sketch. Note that each side is made of up one Pipe A and one Pipe B. The four C Pipes slide into the 4-Way Fittings to create the base. (Be sure to tighten down the fittings using the small eye bolts on them.)
3. Attach canvas to the framework using the Velcro straps.
4. If using game outdoors, it is strongly suggested that you use the stakes provided on either side of the bottom supports. Use sandbags on pavement. And in a breeze, use sandbags with the stakes.
5. Never fold up canvas wet. Always allow to dry thoroughly first.

## **Canvas Care**

1. If game becomes wet, dry thoroughly before storing.
2. Fold the canvas *inward* to help protect and keep it clean.
3. Canvas can be cleaned with rubbing alcohol when necessary. If your game involves Velcro, clean the hook and loop fabric with dry brush to knock out the dirt. If Velcro fabric is badly soiled, use upholstery cleaner.

## **Twister Display**


49207 Calcutta Smith Ferry Road

East Liverpool, Ohio 43920

1 800 637-3656 — 1 (330) 386-1270

[www.twisterdisplay.com](http://www.twisterdisplay.com)

# *Tic-Tac-Toss*



## Twister Display

49207 Calcutta Smith Ferry Road

East Liverpool, Ohio 43920

1 800 637-3656 — 1 (330) 386-1270

[www.twisterdisplay.com](http://www.twisterdisplay.com)

# *Tic-Tac-Toss*

## **Safety Instructions**

1. Use only under adult supervision.
2. Be sure that there is plenty of clearance between the player and spectators.
3. Keep spectators clear from the sides and back of canvas to prevent them from being struck by a deflected or errant throw.
4. If using game outdoors, it is strongly suggested that you use the stakes provided on either side of the bottom supports. Use sandbags on pavement. And in a breeze, use sandbags with the stakes.
5. **NEVER USE THE GAME IN STRONG WINDS OR LIGHTENING!!**
6. Use caution when setting up or taking down the game. The sections of tubing can come apart and fall down causing injury.
7. Use only the toss items included with the game. Do not use hard balls or other hard objects.

## **Twister Display**

*49207 Calcutta Smith Ferry Road*

*East Liverpool, Ohio 43920*

1 800 637-3656 — 1 (330) 386-1270

[www.twisterdisplay.com](http://www.twisterdisplay.com)

# *Tic-Tac-Toss*

## Parts Prices

<u>Canvas</u>	<u>\$450</u>
<u>Case</u>	<u>\$99</u>
<u>Elbow fitting</u>	<u>\$10</u>
<u>Four-way fitting</u>	<u>\$15</u>
<u>Framework</u>	<u>\$150</u>
<u>Tubing (swedged)</u>	<u>\$20</u>
<u>Tubing (unswedged)</u>	<u>\$20</u>
<u>Tubing (w/rubber feet)</u>	<u>\$15</u>
<u>Stakes (set of 4)</u>	<u>\$5</u>
<u>Tic Tac Toss Balls</u>	<u>\$2</u>

## Twister Display

49207 Calcutta Smith Ferry Road

East Liverpool, Ohio 43920

1 800 637-3656 — 1 (330) 386-1270

[www.twisterdisplay.com](http://www.twisterdisplay.com)