

# Safety

- 1) Blower must have back pressure, meaning it must be attached to a duct to avoid any damage to the motor.
- 2) Keep children away from unit at all times while in operation and/or plugged in.
- 3) Do not put fingers or other objects in unit while in operation and/or plugged in.
- 4) Do not operate in pooled water to avoid electric shock.
- 5) Unit must be kept dry at all times, including motor, wiring and exterior. If unit becomes wet, thoroughly dry before next operation.
- 6) Use only with a grounded plug and/or extension cord to avoid risk of electrical shock or fire. Remember never to use a power cord with any kind of damage or wear.
- 7) Make sure the power source is sufficient to meet the requirements of the blower.
- 8) Keep air intakes clear at all times to avoid clogging or blocking in order to prevent the unit from overheating. Blocking the air intakes could result in a fire or electrical hazards.
- 9) Do not remove any screens or safety guards from the unit to prevent injury to persons and to avoid objects from coming in contact with the blower wheel. Unit damage in this manner will void your warranty.
- 10) Do not operate unit close to any dangerous areas, such as explosive gases, flammables, heaters and unventilated environments; this may result in explosions or electrical hazards.
- 11) Do not use any form of speed control devices. Doing so may risk injury or fire.
- 12) Always place blower on a smooth and leveled surface for safe operation.
- 13) Do not operate in stacked position.
- 14) Do not use unit if damaged.
- 15) Before cleaning or servicing, unplug unit.
- 16) All blowers in operation must be supervised at all times.
- 17) Do not expose to rain, water or snow.
- 18) Outdoor use: unit must be connected to a G.F.C.I (ground fault circuit interrupter) protected receptacle.